

# Sherman L-Net and Frame

**CAUTION: THE CUT ENDS OF PIPE MAY HAVE SHARP EDGES**

1. Layout your pieces and make sure that you have all of the pieces and you know which piece corresponds to each letter.
2. Assemble the frame as per the drawing from the ground up. Do not drill screws.
3. After frame is assembled, drill a screw through both pipes, at every joint. The screws will drill themselves in with a little pressure, no guide hole is necessary.
4. Slide net over frame like a pillowcase.

